

FIG. 1






FIG. 2




09731981.120800

FIG. 3



09731981-120800

FIG. 4




008021" T86TE.60

Diagram of a remote control 12. The layout includes:

- Top Section:** A circular button labeled "PWR" (46) and a rectangular button (47).
- Second Row:** An oval button labeled "EPG" (48) and an oval button labeled "D-CHG" (49).
- Third Row:** An oval button labeled "DAIL" (51) and an oval button labeled "GENR" (49).
- Fourth Row:** An oval button labeled "BACK" (51) and an oval button labeled "ESC" (50).
- Fifth Row:** An oval button labeled "MENU" and an oval button labeled "DISP".
- Navigation Section:** A central square button labeled "OK" (43) surrounded by four triangular buttons: up (42), down (44), left (41), and right (45).
- Numeric Keypad:** A 3x3 grid of circular buttons labeled 1 through 9, with a circular button labeled 0 below the 8 and 9 buttons.
- Bottom Section:** Two columns of buttons. The left column has a circular button with a "+" sign and a circular button with a "-" sign, with the label "VOL" below the "-" button. The right column has a circular button with an upward-pointing triangle and a circular button with a downward-pointing triangle, with the label "CH" below the downward-pointing triangle button.

FIG. 6



30





FIG. 8




008027 1867460

FIG. 9



0971981-1E600

FIG. 10



09731981.120800